# Sheet film pinhole camera (wood)

Three dimensional view


Side view

End view (pressure panel removed)

Pressure panel

Top view (with pressure panel)

C

G   L

I

Top view (pressure panel removed)

C

G

Shutter

Screw

Shutter Screw